

## QUICK INSTALLATION GUIDE

Team Edition

### 1 Introduction

A PowerFactory *Team Edition* installation consists of a central licence server, a central database server and several clients running PowerFactory (as depicted in the [installation overview](#)<sup>1</sup>).

This document gives a short overview of the next steps necessary to use the software. You can find more detailed information about the installation process and licence activation in our "Getting Started" and "Installation Manual". Both documents are available on the [download area](#)<sup>2</sup> for registered users on our homepage.

Please note the following general points before proceeding:

1. Prior to first use, the licence needs to be activated once. This process requires an active internet connection.
2. For softkeys online: The use of a softkey-licence in a virtual environment is not possible and will be prevented. Kindly request a USB dongle for this purpose.
3. The licence validity needs to be refreshed on a 30-day basis. This process requires an active internet connection.
4. The software installation requires administrator rights.

### 2 New Installation

#### LICENCE SERVER

##### 1. User Registration

Access to our download area and the customer portal of our support centre is reserved for registered users. User registrations must be performed by yourself. If you do not have a user account yet, kindly apply for one via our online [user registration form](#)<sup>3</sup>. For authentication you will be asked for your company login details from the licence agreement.

##### 2. Download

Please download the "Licence Component Bundle" from the [download area](#)<sup>2</sup> for registered users. Kindly use the access credentials of one of your registered users (see item 1).

##### 3. Installation

Please install the bundle on the computer that will serve as licence server. An installation assistant will help you navigate through the necessary installation processes.

##### 4. Licence Activation

Please note, that each licence needs to be activated once before it can be used. Therefore, immediately

<sup>1</sup> <https://www.digsilent.de/en/licence-and-installation-overview.html>

<sup>2</sup> <https://www.digsilent.de/en/powerfactory-download.html>

<sup>3</sup> <https://www.digsilent.de/en/powerfactory-user-registration.html>

after the installer finishes a configuration assistant will start. This assistant helps you to activate your licence and configures your computer to run as a licence server.

When requested by the assistant, enter the activation key from your licence agreement and click on "Activate" button. Afterwards continue with the assistant.

For USB dongles only: Plug the not yet activated USB dongle into your computer before beginning with the activation process.

#### DATABASE SERVER

Please follow the instructions given by the vendor of the database system. An overview and some configuration details for usage with PowerFactory can be found in the above mentioned "Installation Manual", chapter 6.

#### CLIENT COMPUTER

##### 1. **Download**

Please download the "PowerFactory installation package" from the [download area](#)<sup>2</sup> for registered users. Kindly use the access credentials of one of your registered users (see item 1 of previous section).

##### 2. **Installation**

Install PowerFactory with the help of this installation program on all client computers (or alternatively on your terminal server).

##### 3. **Configuration**

After the installer finishes a configuration assistant will start. This will guide you through the configuration of PowerFactory. When coming to the licence configuration, please either select automatic search or manually select the already installed licence server. Afterwards configure the database settings. Then continue with the assistant.

Please refer to the above mentioned "Getting Started" guide for more details.

## 3 Update

#### LICENCE SERVER

##### 1. **Licence Update**

Start the licence manager "Licence Manager" from the Windows Start menu "Start → PowerFactory Licence Components → Licence Manager". Choose "Update Licence" and follow the indicated steps.

After the update has been completed the new licence will be available to the clients immediately.

#### CLIENT COMPUTER (optional)

If you want to upgrade to the latest PowerFactory version, please follow steps 1 to 3 of the steps for a new installation (see above).

Please note, in case of a PowerFactory update, a data migration might be required afterwards. This is executed automatically by the application at next program start and requires PowerFactory administrator credentials.

## 4 Support

For comments or questions kindly contact our support team via our support centre which is available to holders of new licences or valid maintenance contracts under <https://www.digsilent.de/en/support.html>



For more information, visit  
[www.digsilent.de](http://www.digsilent.de)



DigSILENT GmbH  
Heinrich-Hertz-Straße 9  
72810 Gomaringen (Germany)  
T: +49 7072 9168-0  
[mail@digsilent.de](mailto:mail@digsilent.de)



DigSILENT GmbH is certified to the ISO 9001:2015 standard. More information is available at [www.tuv-sud.com/ms-cert](http://www.tuv-sud.com/ms-cert).